



Coliform Sampling Procedure

331-225 • 10/31/2024

Coliform Sampling Procedure

We recommend that you follow these steps when collecting your sample. If instructions from your lab are different, please call us for clarification.

Most sample kits contain a:

- ◆ Sample bottle.
- ◆ Lab slip.
- ◆ Rubber band.

Protect the sample bottle from contamination before and after sampling. Don't rinse it and don't expose it to direct sunlight, heat, or unsanitary conditions.

Step One

Follow your Coliform Monitoring Plan to collect routine, repeat, and raw source samples from sites throughout the distribution system. You must collect raw source samples from sites prior to all treatment and close to the source while the source pump is running.

Sample taps should represent the water in your distribution system. Avoid poor sample sites such as swivel faucets, hot and cold mixing faucets (with a single lever), leaky or spraying faucets, drinking fountains, janitorial sinks, frost-free hose bibs, and faucets below or near ground level.

Step Two

Remove any attachments from the faucet, including aerators, screens, washers, hoses, and water filters. If you choose to disinfect the sample site before collecting the sample, be sure to flush the site thoroughly to remove all disinfectant.

Step Three


Turn on the cold water only and let it run with a steady stream for at least five minutes. Before collecting the sample, turn the water down to a thin stream (about the width of a pencil), then let the water run one minute. If you chlorinate your system, measure the free chlorine residual and note the measurement on the lab slip.

Step Four

There may be some liquid or powder in the sample bottle to neutralize chlorine. Do not rinse it out.

Step Five

To avoid contamination while taking the sample, hold the bottle near the bottom with one hand, hold the top of the cap with the other, and then unscrew the cap.



Do not set the cap down, touch any part of the cap that touches the bottle, or let anything touch the rim of the bottle or the inside of the cap.

Step Six

Hold the bottle under the stream of water. Be careful not to let the bottle touch the sample tap. Fully fill the bottle to the neck or indicated fill line. Don't allow it to overflow. Remove the bottle from the water flow and carefully screw the cap back on.



Step Seven

Complete the lab slip. If there was anything unusual about the sample collection, note it on the lab slip.



Lab forms vary. It is important to include at least the following information.

- ◆ Collection date and time.
- ◆ Water system ID number.
- ◆ Contact information.
- ◆ Type of sample (check ONLY ONE Type: Routine, Repeat, Raw, or For Information Only).
- ◆ System type (Group A or B).
- ◆ Water system name.
- ◆ Chlorine residual—even if it's zero.
- ◆ Sample location (street address or other location identifier).

Step Eight

Secure the lab slip to the bottle with the rubber band. Deliver the sample to a certified lab or a designated drop-off location for the lab as soon as possible. Lab analysis must begin within 30 hours after you collect your sample.

Related Resources

[Revised Total Coliform Rule \(RTCR\) webpage](#). An explanation of the federal RTCR, including explanations of key terms, assessments, and violations of the rule.

For More Information

[Eastern Region](#), Spokane Valley 509-329-2100.

[Northwest Region](#), Kent 253-395-6750.

[Southwest Region](#), Tumwater 360-236-3030.



To request this document in another format, call 1-800-525-0127. Deaf or hard of hearing customers, please call 711 (Washington Relay) or email doh.information@doh.wa.gov. If in need of translation services, call 1-800-525-0127.